



NTDOB...H
 NTCLB...H
 NTDLB...H



ITEM	PART NAME	NTDOB242H0393	NTDOB125H0451	NTDOB175H0464	NTDOB175H0482	NTDOB175H0519	NTDOB150H0531	NTDOB256H0544
1	Nozzle holder body	52/301	52/312	52/336	52/336	52/421	52/448A	52/457
3	Spring spindle	-	52/314A	52/314D	52/314D	52/314D	52/314C	52/458B
5	Spring - injector	52/305	52/329	52/329	52/329	52/329	52/329	52/329
8	Cap nut	-	-	52/334	52/334	52/420	52/449	52/467
9	Seal - cap nut	-	NM5/33	113/97	113/97	113/97	113/97	235/29
10	Screw- adjusting	-	52/319	52/332	52/332	52/332	52/332	-
11	Locknut - adjusting screw	-	52/317	112/28	112/28	112/28	112/28	386/1
12	Vent screw	-	-	-	-	52/190	-	-
19	Inlet connector	-	52/321	52/335	52/323	7024/58	52/335	-
20	Edge filter	-	-	7024/57	-	7024/57	7024/57	-
22	Washer - Inlet connector	-	106/83	5936/95L	5936/95L	5936/95L	5936/95E	-
26	Nozzle nut	52/307	52/318	52/318	52/318	52/318	52/318	52/318
27	Transfer block	52/306	52/313	52/313	52/313	52/313	52/313	52/313
31	Blanking plug	-	52/326	-	-	-	-	-
41	Shlm	NM2/76--80 (AR)	-	-	-	-	-	-
44	Thrust cap - guided	-	52/315	52/315	52/315	52/315	52/315	-
ND	Thrust cap	52/304	-	-	-	-	-	52/461

NTDOB...H